



2019)

ity-Multi Slings-Rev 02 [09

99954-Quick

OUICK REFERENCE GUIDE

Activity/Multi Sling



Sling Positioning

Applying sling from a seated position (Multi Sling only)



Prepare the sling by passing the elasticized waist belt through the loops in the chest belt.

Stand behind or to the side of

the intended user and put the

belt around their waist. Have

them lean forward (assist if

needed). Tighten the waist belt

and then fasten the chest belt.



Applying Multi Sling from a supine position

Prepare the sling by passing the elasticized waist belt through the loops in the chest belt.

Lay the intended user on the

side and position the belt at

their waist. Roll over the user

and secure the belt around

their waist. Once the belt is

If additional supports are

lifting. See: Accessories.

required, attach them prior to

tightened, fasten the chest belt.



Applying Activity Sling from a supine position

The Activity Sling can only be fitted when the child is in the supine position. Begin by sliding up the child's legs.

Once the sling has been

fitted onto the body, put the

child's arms through the side

behind the child's neck as far as

openings. Pull up the sling

possible.

Accessories



25107 Hip belt (Multi Sling only) The hip belt is designed to put equal pressure on both hip joints in order to achieve a better balance and distribute the patient's weight more evenly. Ideal for patients with functional impairments.

25146 Waist belt with lock (Multi Sling only)

The Multi Sling comes equipped with a waist belt with Velcro. As an option, the belt may be purchased with a safety lock for added security.



21180 Extension straps Used to adjust sling straps to alter seated positioning.



Important! Have the user hold onto something for stability and/or to enable them to help with the lifting process. Tighten waist belt as much as comfortably possible to ensure belt sits in place during lift.



For dressing/undressing, secure the rear lifting straps to the lift bar. The user will lean forward slightly. Lift 10 to 30cm, ensuring user is stable.



For exercise or other uses. attach all four straps for an upright position.



The greater the user's weight, the greater the risk the chest belt may slide up.

Important! Have the user hold onto something for stability and/or to enable them to help with the lifting process. Tighten waist belt as much as comfortably possible to ensure belt sits in place during lift.

Depending on required lift,

secure appropriate straps to lift





Important! The child's head must be below the top of the sling. Do not let the material fold under the patient!

Lift the child to a standing position.



























25150 Neck cushion (Multi Sling only)

Provides extra support and comfort for the head.





25108 Groin support (Multi Sling

Keeps the chest belt in place and prevents it from sliding up. The groin support comes standard with the Multi





OUICK REFERENCE GUIDE





Lower the lift and secure all shoulder straps securely. Keep one hand behind the child's head at all times if the sling is

not fully extended.

